



HARLEQUIN MESH



A BACK ADJUSTMENT LOCK

When back rest is in desired position turn handle backwards to lock.



B BACK ANGLE ADJUSTMENT

Turn handle to adjust tension.




C SEAT HEIGHT ADJUSTMENT

To lift:

Remove body weight from seat, press lever upwards.


To lower:

Sit on seat, press lever upwards.




D SEAT DEPTH ADJUSTMENT

Lift lever to release, push forward or backward to desired position, release to lock.



ARMS



A8

Black Height Adjustable Arms

Lift Lever to Adjust Height

Adjustment: ↑↓